
VLSI Technology Assignment

SAURABH KUMAR SC22B146

Realize the structure.

- 1 write all the steps with picture.
- Mention the recipe also.
- 3 You are starting with P-Si.
- There is deposition of Sioz.
- 5) PR can be used as mask for RIE (300°C).



////// -> SiO2 (1 µm) (wet oxa) - Pt (50nm)

→SiO2 (100 mm)
(Aug oxdn)

Solution:

Step-D: Wafer Cleaning: RCA clean (Hemoves organics and particles).

RCA-1: NH40H + H202 + H20 at 75-80°C (5-10 minutes)

RCA-2: Hal + 1202 + 120 at 75-80°C (5-10 minutes)

HF dip: 1% HF to Hemore native oxide before oxidation (10-30, sec).

Result:

P-si wafer (clean)

Step-D: Wet Oxidation (for 1 um oxide layer in center)

furnace at 1000°C Equipment: N2+H20 vertical sioz water -> water -> 80°C

> Si +2H20 - wet > SiO2 +2H21 [Fox 90-120 minutes]

To produce 1 µm Sioz, ~0.5 µm si will be consumed.

1111111/slp2///// \$1 Hm Result: p-Si

Step-3: Patterning central SiO2 Photolithography: (1) Apply positive photosesist (PR) on oxide layer and spin the water at high speed. Bake the water at ~ 90-100°C to evaporate the solvent.

photomesiste (positive)

p-si

p-si

p-si

p-si (ii) Align a photo mark (10 µm wide) over the PR. (i) Exposure: Expose the photoresist to UV light through the mark. Development: Immerse the water in developer solution. This dissolves the exposed region of the PR. 1) Hourd bake at ~120"-150" to striengthen the pattern. 1 1 1 un light Development Wet etching using HF: Selective etching of sioz. CF4 < 2300°C > CF3 + f* Hz + F* - HF HF + SiD2 -> SiFe 1 + H21 [constant etching reate] [~ 15 minutes] Result: 1 pm PR Sioz

PR strupping: Remove PR strup using 1,504 + 1/202 solution.

Perunt: umy 1777 sioz

Tomm
P-si


Step-19: Dony Oxidation (for 100 nm oxide layer at conners) Equipment:

Oz (dry)


(pwie) furnace at ~1000°C voltical Si wager Si + 0 21 1000°C SiO2 (solid) Res To produce 100 nm sioz, around so non si will be consumed. This oscidation will only affect the Si substructe at no reaction with 5102 is possible. Also werent 5002 layer is much thicker than one being farmed. side 17/1/11 1 mm side Result: Sty 19: Patterning Corner Sio2 Photo lithography: (Apply negative photoresist on sioz layer, spincoat and bake the water to evaporate the solvent. P-Si PR (-ve) 1 Align a patterned mask over the PR as In the figure. (1) Expose the PR to UV through the mark. (i) Apply developer, to Hernove unwanted PR. 1 Hard bake at ~120°-150°c to storengthen the fattern. 1 UV

SiOZ Exposure sio





PR stripping: Use H2504 + H202 & Alution.



Step 0: Pt Patterning using Littoff.

when the metal layer must not be etched (eg, noble metals like Pt).

Photolithography:


1) Spin-coat a positive photoresist on the water (thickness ~1-2)

1 Soft bake at ~90-100°c to evaposiste the solvents from PR.

1 Use a photomask aligning the window as shown in the figure.

@ Expose to UV light.

1 Immerse in developer to remove the exposed PR.




This will deposit a uniform 50 nm Pt layer everywhereon the exposed 5002 swiface and on top of PR.

Equipment: De Magnetron Sputtering System

- First, add a 5-10 nm Ti or Cr adhesion layer before Pt deposition (via sputtering) to improve the Pt adhesion.

-> Sprutted Pt coats both on the substrate and photogenist sidewalls. [solution: use directional deposition, e.g., evaporation].

Result:



Fit-Off: Soak the water in acctone to dissolve the PR. This litt offs the metal on top of PR.

I Metal Hemains only on the area where no PR was present

→ Ringe in Proposopy alcohol to Hernove acetone yesidues.

→ Anally stinge with DI water to eliminate IPA's particles.

Lo Duying: N2 gun or spin obujer to prevent water marks.

final structure:

